

SERVICE SUPPORT HANDBOOK

www.mhial.com.au


⚠ WARNING

The information contained within this 'Service Support Handbook' is for the use by qualified licenced personnel only. Additionally, the information presented here is not a replacement or substitute to the Manufacturers Technical Manual literature.

Please do not remove any covers, or attempt any repair or measurement on any MHI LTD. product, unless you are suitably qualified and licenced to do so.

Note that applicable models released from 2014 are DRED (AS4755) compliant. This means that the outdoor unit has 4 extra terminals as per example indicated below. Please only connect a DRED specified relay to these terminals if and where applicable. They are not to be connected to the indoor unit. The outdoor unit to indoor unit interconnecting terminal block is to the left/top on RAC products and a separate terminal block on PAC products.


RAC products – Terminal block wiring connections – (example)




RAC Products

Display pattern of the indoor unit run and timer light during an external DRM input

Display in DRED mode



Display in DRED mode during Defrost operation




1:1 Split Systems - Remote Controls of SRK, DXK, SRF, SRR


Before Proceeding to RAC Self Diagnosis Information, ensure the correct Remote Control is being used

Indoor Unit Model No.	Remote Control P/No.	RC Sub.	Refrigerant	Cycle	Inverter Type	SC-BIKN	D.R.E.D.	TM
SRK--ZAA	RKS502A503		R22	Reverse cycle	Wall mount	No	No	
SRK--ZD-S, SRK--ZDX-S	RMA502A001	001C	R410A	Reverse cycle	Wall mount	No	No	
SRK--ZEA-S, SRK--ZEA-S1	RKW502A200	200D	R410A	Reverse cycle	Wall mount	No	No	
SRK--ZFX-S, SRK--ZGX-S	RKW502A200B		R410A	Reverse cycle	Wall mount	No	No	
SRK--ZHX-S	RKX502A001C	007C	R410A	Reverse cycle	Wall mount	Yes	No	
SRK--ZIX-S			R410A	Reverse cycle	Wall mount	Yes	No	
SRK--ZJX-S, SRK--ZJX-S1			R410A	Reverse cycle	Wall mount	Yes	No	
SRK--ZG-S			R410A	Reverse cycle	Wall mount	No	No	
SRK--ZJ-S, SRK--ZJ-S1			R410A	Reverse cycle	Wall mount	Yes	No	
SRK--ZK-S	RKW502A200	200D	R410A	Reverse cycle	Wall mount	Yes	No	
SRK--ZL-S			R410A	Reverse cycle	Wall mount	Yes	No	
SRK--ZMA-S	RLA502A700B	700R	R410A	Reverse cycle	Wall mount	Yes	Yes	
SRK--ZMXA-S			R410A	Reverse cycle	Wall mount	Yes	Yes	
SRF--ZMXA-S	RLA502A700C	700S	R410A	Reverse cycle	Floor mount	Yes	Yes	
SRR--ZM-S	RLA502A701C	700C	R-410A	Reverse cycle	Ceiling concealed	Yes	Yes	
SRK--ZMP-S	RKX502A001P	007P	R410A	Reverse cycle	Wall mount	No	No	
SRK24YMA-S	RLA502A700D	700T	R410A	Cool only	Wall mount	Yes	Yes	
SRK--YJ-S, SRK--YL-S	RKX502A001	007	R410A	Cool only	Wall mount	No	No	
SRK--ZSA-W	RLA502A701L		R32	Reverse cycle	Wall mount	Yes	Yes	Avanti
SRK--ZRA-W	RLA502A700R		R32	Reverse cycle	Wall mount	Yes	Yes	Bronte
SRK--ZSXA-W			R32	Reverse cycle	Wall mount	Yes	Yes	Avanti +
SRK24YRA-W	RLA502A700T		R32	Cool only	Wall mount	Yes	Yes	Bronte
SRK--YSA-W			R32	Cool only	Wall mount	Yes	Yes	Avanti
DXK--Z3-S, DXK--Z5-S	RKX502A001P	007P	R410A	Reverse cycle	Wall mount	No	No	
DXK--ZJ-S	RKX502A001C	007C	R410A	Reverse cycle	Wall mount	Yes	No	
DXK--Z4-S	RKW502A200	200D	R410A	Reverse cycle	Wall mount	Yes	No	
DXK--ZL-S			R410A	Reverse cycle	Wall mount	Yes	No	
DXK06ZM-S	RLA502A701B	700B	R410A	Reverse cycle	Wall mount	Yes	No	
DXK--ZMA-S	RLA502A700B	700R	R410A	Reverse cycle	Wall mount	Yes	Yes	
DXK--ZSA-W	RLA502A701L		R32	Reverse cycle	Wall mount	Yes	Yes	Avanti
DXK--ZRA-W	RLA502A700R		R32	Reverse cycle	Wall mount	Yes	Yes	Bronte


RKX502A001C



RKW502A200




RLA502A700B / RLA502A701C



RLA502A701L

Operation section



Refrigerant Piping Information - Current Models

Model	Gas Type	Precharged Piping Length (m)	Max Piping Length (m)	Vertical Pipe Length (m)		Factory Charge (Kg)	Additional Charge (gr per m)	Pipe Sizes (mm)	
				O/D above	I/D above			Liquid Pipe	Gas Pipe
SRC95ZRA-W	R32	15	30	20	20	2.00	25	9.52	15.88
SRC71,80ZRA-W	R32	15	30	20	20	1.60	25	6.35	15.88
SRC24YRA-W	R32	15	30	20	20	1.60	25	6.35	15.88
SRC63ZRA-W	R32	15	30	20	20	1.25	20	6.35	12.7
SRC50ZSA-W	R32	15	25	15	15	1.05	20	6.35	12.7
SRC25,35ZSA-W	R32	15	20	10	10	0.75	20	6.35	9.52
SRC20ZSA-W	R32	15	20	10	10	0.58	20	6.35	9.52
SRC18YSA-W	R32	15	25	15	15		20	6.35	12.7
SRC13YSA-W	R32	15	20	10	10		20	6.35	9.52
SRC10YSA-W	R32	15	20	10	10		20	6.35	9.52
DXC33ZRA-W	R32	15	30	20	20	2.00	25	9.52	15.88
DXC24,28ZRA-W	R32	15	30	20	20	1.60	25	6.35	15.88
DXC21ZRA-W	R32	15	30	20	20	1.25	20	6.35	12.7
DXC18ZSA-W	R32	15	25	15	15	1.05	20	6.35	12.7
DXC09,12ZSA-W	R32	15	20	10	10	0.75	20	6.35	9.52
DXC06ZSA-W	R32	15	20	10	10	0.58	20	6.35	9.52
DXC05Z5-S	R410A	10	15	10	10	0.655	20	6.35	9.52
SRC50,60ZMXA-S	R410A	15	30	20	20	1.5	20	6.35	12.7
SRC25,35ZMXA-S	R410A	15	15	10	10	1.2	N/A	6.35	9.52
SRC17ZMP-S, 20ZMP-S	R410A	10	15	10	10	0.655	20	6.35	9.52

SCM Multi Head Series – *Note that the maximum one way piping length for individual ports is 25 metres

Model	Gas Type	Precharged Piping Length (m)	Max Piping Length (m) for all rooms	Vertical Pipe Length (m)		Factory Charge (Kg)	Additional Charge (gr per m)	Pipe Sizes (mm)	
				O/D Above	I/D Above			Liquid Pipe	Gas Pipe
SCM100,125ZM-S	R410A	50	90	20	20	6.0	20	6.35	9.52
SCM71,80ZM-S1	R410A	40	70	20	20	3.15	20	6.35	9.52
SCM60ZM-S	R410A	40	40	15	15	2.5	N/A	6.35	9.52
SCM50ZS-S	R410A	40	40	15	15	2.50	N/A	6.35	9.52
SCM40,45ZS-S	R410A	30	30	15	15	1.90	N/A	6.35	9.52

PAC – Current Models

Model	Gas Type	Precharged Piping Length (m)	Maximum Piping Length (m)	Vertical Pipe Length (m)		Factory Charge (Kg)	Additional Charge (gr per m)	Pipe Sizes (mm)	
				O/D Above	I/D Above			Liquid Pipe	Gas Pipe
FDCA71VNXA	R410A	30	50	30	15	2.95	60	9.52	15.88
FDCA100VN	R410A	30	50	30	15	3.8	60	9.52	15.88
FDC100VNP	R410A	15	30	20	20	2.55	60	9.52	15.88
FDCA100,125,140VNX FDCA100,125,140VSX	R410A	30	100	30	15	4.5	60	9.52	15.88
FDCA160VSA FDCA200VSA	R410A	30	35	30	15	7.2	120	12.7	22.22
		30	70	30	15	7.2	120	12.7	25.4/ 28.58

Refrigerant Piping Information – R410A

Historical Models

Model No.	Precharged Piping Length (m)	Max Piping Length (m)	Vertical Pipe Length (m)		Vertical Pipe Length (m)	Additional Charge (gr per m)	Pipe Size (mm)	
			O/D Above	O/D Above			Liquid Pipe	Gas Pipe
SRC92ZMA-S	15	30	20	20	3.15	25	6.35	15.88
SRC80ZMA-S	15	30	20	20	2.2	25	6.35	15.88
SRC24YMA-S	15	30	20	20	1.8	25	6.35	15.88
SRC63,71ZMA-S	15	30	20	20	1.8	25	6.35	15.88
SRC50ZMA-S	15	25	15	15	1.35	20	6.35	12.7
SRC25,35 ZMA-S	15	15	10	10	1.15	N/A	6.35	9.52
SRC20ZMA-S	15	15	10	10	0.75	N/A	6.35	9.52
SRC50,60ZMXA-S	15	30	20	20	1.5	20	6.35	12.7
SRC20,25,35ZMXA-S	15	15	10	10	1.2	N/A	6.35	9.52
SRC18YL-S/YJ-S	15	25	15	15	1.35	20	6.35	12.7
SRC13YL-S/YJ-S	15	15	10	10	1.05	N/A	6.35	9.52
SRC10YL-S/YJ-S	10	15	10	10	0.75	20	6.35	9.52
SRC20,25,ZD/ZF/,ZG	15	15	10	10	0.9	N/A	6.35	9.52
SRC20,25ZJ-S	15	15	10	10	0.75	N/A	6.35	9.52
SRC35ZD/ZG	15	15	10	10	1.1	N/A	6.35	9.52
SRC35ZJ-S	15	15	10	10	1.05	N/A	6.35	9.52
SRC20ZJ-S1	15	15	10	10	0.75	N/A	6.35	9.52
SRC25,35ZJ-S1	15	15	10	10	1.15	N/A	6.35	9.52
SRC50ZD,ZJ-S,ZJ-S1	15	25	15	15	1.35	20	6.35	12.7
SRC20,25,35ZDX/ZFX/ZGX/ZIX /ZJX-S/ZJX-S1	15	15	10	10	1.2	N/A	6.35	9.52
SRC50,60ZFX,ZGX,ZHX,ZIX	15	30	20	20	1.4	20	6.35	12.7
SRC50,60ZJX-S	15	30	20	20	1.5	20	6.35	12.7
SRC63,71,80ZEA-S/S1/S2	15	30	20	20	1.9	25	6.35	15.88
SRC63,71,80ZK-S	15	30	20	20	1.8	25	6.35	15.88
SRC80ZL-S	15	30	20	20	2.2	25	6.35	15.88
SRC92ZL-S	15	30	20	20	3.15	25	6.35	15.88
DXC32ZMA-S	15	30	20	20	3.15	25	6.35	15.88
DXC28ZMA-S	15	30	20	20	2.2	25	6.35	15.88
DXC21,24ZMA-S	15	30	20	20	1.8	25	6.35	15.88
DXC18ZMA-S	15	25	15	15	1.35	20	6.35	12.7
DXC09,12ZMA-S	15	15	10	10	1.15	N/A	6.35	9.52

Refrigerant Piping Information – R410A

Historical Models

Model No.	Precharged Piping Length (m)	Max Piping Length (m)	Vertical Pipe Length (m)		R410A Factory Charge (Kg)	Additional Charge (gr per m)	Pipe Size (mm)	
			O/D Above	I/D Above			Liquid Pipe	Gas Pipe
DXC06ZM-S	15	15	10	10	0.75	N/A	6.35	9.52
DXC05Z5-S	10	15	10	10	0.655	20	6.35	9.52
DXC32ZL-S	15	30	20	20	3.15	25	6.35	15.88
DXC28ZL-S	15	30	20	20	2.2	25	6.35	15.88
DXC21,24,28Z4-S	15	30	20	20	1.8	25	6.35	15.88
DXC18Z3-S/ZJ-S	15	25	15	15	1.35	20	6.35	12.7
DXC09,12ZJ-S	15	15	10	10	1.15	N/A	6.35	9.52
DXC12Z3-S	15	15	10	10	1.05	N/A	6.35	9.52
DXC09Z3-S	10	15	10	10	0.75	20	6.35	9.52
DXC24VNX	30	50	30	15	2.95	60	9.52	15.88
DXC34,43,48VNX	30	100	30	15	4.5	60	9.52	15.88
DXC55VS	30	35/70	30	15	7.2	120	12.7	22.22
SCM40ZG-S	30	30	15	15	1.4	N/A	6.35	9.52
SCM45ZG-S	20	30	15	15	1.6	20	6.35	9.52
SCM48ZG-S	40	40	15	15	1.95	N/A	6.35	9.52
SCM60ZG-S	30	40	15	15	2.2	20	6.35	9.52
SCM80ZG-S	40	70	20	20	3.15	20	6.35	9.52
SCM40ZJ-S	30	30	15	15	2	N/A	6.35	9.52
SCM50,60ZJ-S/ZJ-S1	40	40	15	15	2.5	N/A	6.35	9.52
SCM71,80ZJ-S/ZJ-S1	40	70	20	20	3.15	20	6.35	9.52
SCM100,125ZJ-S/ZJ-S1	50	90	20	20	6	20	6.35	9.52
SCM40ZM-S	30	30	15	15	2.0	N/A	6.35	9.52
SCM50_60ZM-S	40	40	15	15	2.5	N/A	6.35	9.52
SCM71_80ZM-S	40	70	20	20	3.15	20	6.35	9.52
FDCA71VNX	30	50	30	15	2.95	60	9.52	15.88
FDCVA151,201HEN	30	40	30	15	1.55	20	6.35	12.7
FDCVA251HEN	30	40	30	15	1.75	20	6.35	15.88
FDCVA302HENR/HENAR	30	50	30	15	2.95	60	9.52	15.88
FDCVA402,502,602HENR/HENAR	30	50	30	15	3.8	60	9.52	15.88

RAC - SELF-DIAGNOSIS INFORMATION

Inverter RAC Indoor Unit		SRK	ZD, ZF, ZG, ZJ, ZJ-S1,ZMA,ZSA,ZDX,ZFX,ZGX,ZHX,ZIX,ZJX,ZJX-S1,ZMXA,ZSXA,ZEA,ZE-S1,ZE-S2,ZK,ZL,YJ,YL,YR,YS				
		SRF	ZIX, ZJX, ZJX-S1,ZMXA,ZSXA				
		DXK	Z3,Z4,ZJ,ZL,ZM,ZMA,ZSA,ZRA				
Inverter RAC Outdoor Unit		SRC	ZD, ZF, ZG, ZJ, ZJ-S1,ZMA,ZSA,ZDX,ZFX,ZGX,ZHX,ZIX,ZJX,ZJX-S1,ZMXA,ZSXA,ZEA,ZE-S1,ZE-S2,ZK,ZL,YJ,YL,YR,YS				
		DXC	Z3,Z4,ZJ,ZL,ZMA,ZSA,ZRA				
Indoor unit display panel		Outdoor Control PCB, Red LED	Wired R/C display	Description of Trouble	Cause	Display (flashing) condition	
Run Light	Timer Light						
1-time flash	ON	--	--	Heat exchanger sensor 1 error	Broken heat exchanger sensor 1 wire, poor connector connection *Indoor PCB is faulty	When a heat exchanger sensor 1 wire disconnection is detected while operation is stopped. (If a temperature of -28°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)	
2-time flash	ON	--	--	Room temperature sensor error	Broken room temperature sensor wire, poor connector connection *Indoor PCB is faulty	When a room temperature sensor wire disconnection is detected while operation is stopped. (If a temperature of -45°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)	
3-time flash	ON	--	--	Heat exchanger sensor 2 error	Broken heat exchanger sensor 2 wire, poor connector connection. *Indoor PCB is faulty	When a heat exchanger sensor 2 wire disconnection is detected while operation is stopped. (If a temperature of -28°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)	
4-time flash	ON	-	E 9	Drain trouble	Defective drain pump (DM), broken drain pump wire • Anomalous float switch operation. Defective indoor PCB faulty	If the float switch OPEN is defected for 3 seconds continuously or if float switch connector or wire is disconnected.	
6-time flash	ON	--	E 16	Indoor fan motor error	Defective fan motor, poor connector connection	When conditions for turning the indoor unit's fan motor on exist during air conditioner operation, • Defective fan motor, poor an indoor unit fan motor speed of 300 min-1 or lower is measured for 30 seconds or longer. (The air conditioner stops.)	
Keeps flashing	1-time flash	8-time flash	E 38	Outdoor air temperature sensor error	Broken outdoor air temp sensor wire, poor connector connection • Outdoor PCB is faulty	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or lower is detected for within 20 seconds after power ON. (The compressor is stopped.)	
Keeps flashing	2-time flash	8-time flash	E 37	Outdoor heat exchanger sensor error	Broken heat exchanger sensor wire, poor connector connection. • Outdoor PCB is faulty	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or lower is detected for within 20 seconds after power ON. (The compressor is stopped.)	
Keeps flashing	4-time flash	8-time flash	E 39	Discharge pipe sensor error	Broken discharge pipe sensor wire, poor connector connection. • Outdoor PCB is faulty	-25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. (The compressor is stopped.)	
ON	1-time flash	1-time flash	E 42	Current cut	Current Cut	Compressor locking, open phase on compressor output, short circuit on power transistor, closed service valve, EEV not opening	
ON	2-time flash	2-time flash	E 59	Trouble of outdoor unit	Broken compressor wire • Compressor blockage	When there is an emergency stop caused by trouble in the outdoor unit, or the input current value is found to be lower than the set value. (The air conditioner stops.)	
ON	3-time flash	3-time flash	E 58	Current safe stop	• Overload operation • Overcharge • Compressor locking	When the compressor command speed is lower than the set value and the current safe has operated. (the compressor stops)	
ON	4-time flash	1-time flash	E 51	Power transistor error	Broken power transistor	When the power transistor is judged breakdown while compressor starts.(The compressor is stopped.)	
ON	5-time flash	5-time flash	E 36	Over heat of compressor	Gas shortage, defective discharge pipe sensor, service valve is closed	When the value of the discharge pipe sensor exceeds the set value. (The air conditioner stops.)	
ON	6-time flash	6-time flash	E 3, E 5	Error of signal transmission	Defective power supply, Broken signal wire, defective indoor/outdoor PCB	When there is no signal between the indoor PCB and outdoor PCB for 10 seconds or longer (when the power is turned on), or when there is no signal for 7 minute 35 seconds or longer (during operation) (the compressor is stopped).	
ON	7-time flash	ON	E 48	Outdoor fan motor error	Defective fan motor, poor connector connection	When the outdoor unit's fan motor speed continues for 30 seconds or longer at 75 min-1 or lower. (3 times) (The air conditioner stops.)	
ON	Keeps flashing	2-time flash	E 35	Cooling high pressure protection	Overload operation, overcharge, Broken outdoor heat exchange sensor wire, Service valve is closed	When the value of the outdoor heat exchanger sensor exceeds the set value.	
2-time flash	2-time flash	7-time flash	E 60	Rotor lock	Defective compressor Open phase on compressor Defective outdoor PCB	If the compressor motor's magnetic pole positions cannot be correctly detected when the compressor starts. (The air conditioner stops.)	
5-time flash	ON	2-time flash	E 47	Active filter voltage error	Defective active filter	When the wrong voltage connected for the power supply. When the outdoor PCB is faulty.	
7-time flash	ON	2-time flash	E 57	Refrigeration cycle system protective control	* Service valve is closed. • Refrigerant is insufficient	When refrigeration cycle system protective control operates.	
7-time flash	1-time flash	4-time flash	E 40	Service valve (gas side) closed operation	* Service valve (gas side) closed • Defective outdoor PCB	If the output current of inverter exceeds the specifications, it makes the compressor stopping. (In heating mode). After 3-minute delay, the compressor restarts, but if this anomaly occurs 2 times within 20 minute after the initial detection.	
--	--	--	E 1	Error of wired remote control wiring	Broken wired remote control wire, defective indoor PCB	The wired remote control wire Y is open. The wired remote control wires X and Y are reversely connected. Noise is penetrating the wired remote control lines. The wired remote control or indoor PCB is faulty. (The communications circuit is faulty.)	

MULTI HEAD - SELF-DIAGNOSIS INFORMATION – Historical Models

Inverter Multi Indoor		SKM	ZD, ZF, ZG			
		SRRM	ZE, ZF			
		STM	ZE, ZF			
Inverter Multi Outdoor		SCM	ZD-S / ZF-S / ZG-S			
Indoor unit display panel		Outdoor main PCB, Red LED	Wired Remote control display	Description of trouble	Cause	Display (flashing) condition
Run Light	Timer Light					
1-time flash	Comes on	Stays off	E 6	Indoor heat exchanger sensor (1) error	Broken heat exchanger sensor (1) Wire. Connector poor connection Disconnected sensor	Broken heat exchanger sensor (1) wire, poor connection
2-time flash	Comes on	Stays off	E 7	Room temperature sensor error	Broken room temperature sensor Wire. Connector poor connection	When room temperature sensor temperature of -20°C or under continued for more than 15 seconds while operation is stopped. (This is not displayed during operation.)
4-time flash	Comes on	Stays off	E 9	Drain abnormality (STM, SRRM only)	Drain at reverse gradient. Float switch defective	Float switch motion
5-time flash	Comes on	Stays off	E 6	Indoor heat exchanger sensor (2) error	Broken heat exchanger sensor (2) Wire. Connector poor connection Disconnected sensor	When heat exchanger sensor (2) temperature of -20°C or under continued for more than 15 seconds while operation is stopped. (This is not displayed during operation.)
6-time flash	Comes on	Stays off	E 16	Indoor fan motor error	Defective fan motor. Connector poor connection	When air conditioner is operating and indoor fan motor is turned ON, indoor fan motor speed of 300 rpm or under continued for more than 30 seconds. (Air conditioner stops.)
7-time flash	Comes on	Stays off	E 6	Closed service valve, indoor heat exchanger sensor (1)	Closed service valve. Heat exchanger sensor (1) is disconnected.	After cooling starts, when the temperature difference at the indoor heat exchanger sensor (1) after 13 minutes and after 16 minutes is greater than -2°C, operation is stopped.
Keeps flashing	1-time flash	Keeps flashing	E 38	Outdoor air temperature sensor	Broken outdoor air temperature sensor wire. Poor connector connection	When outdoor air temperature sensor temperature of -20°C or under continued for more than 10 seconds while operation is stopped. (This is not displayed during operation.)
Keeps flashing	2-time flash	Keeps flashing	E 37	Outdoor heat exchanger sensor	Broken heat exchanger sensor Wire. Poor connector connection	When heat exchanger sensor temperature of -20 °C or under continued for more than 10 seconds while operation is stopped. (This is not displayed during operation.)
Keeps flashing	4-time flash	On for 4 sec & off for 4 sec	E 39	Discharge pipe sensor error	Broken discharge pipe sensor wire. Connector poor connection	After the decision speed has been 0 rps or more for 9 continuous minutes and the discharge pipe sensor has sent a 10 second or more broken wire signal. (Compressor is stopped.)
Keeps flashing	5-time flash	Keeps flashing	E 53	Compressor suction sensor	Broken comp. suction sensor wire. Poor connector connection	When comp. suction sensor temperature of -20°C or under continued for more than 10 seconds while operation is stopped.
Comes on	4-time flash	4-time flash	E 41	Power transistor sensor error	Broken power transistor sensor wire. Connector poor connection	After the decision speed has been 0 rps or more for 9 continuous minutes and the power transistor sensor has sent a 10 second or more broken wire signal. (Compressor is stopped.)
Comes on	1-time flash	1-time flash	E 42	Current Cut	-Compressor locking -Open phase on compressor output. Short-circuit on power transistor	When converter output current which exceeds setting value is detected. (Compressor stops.)
Comes on	2-time flash	2-time flash	E 59	Trouble of outdoor unit	-Defective power transistor -Broken compressor wire -Compressor blockage	When an error with the outdoor unit causes an error stop, or when the input current is measured at 1 A or less for 3 continuous minutes or more. (Compressor is stopped.)
Comes on	3-time flash	3-time flash	E 58	Current safe stop	Overload operation Overcharge	When the decision speed is 30 rps or less and the current save has operated. (Compressor stops)
Keeps flashing	6-time flash	Keeps flashing	E 41	Power transistor error	Broken power transistor	When there is an emergency stop caused by trouble in the outdoor unit, or the input current value is found to be lower than the set value continuously for 3 minutes or longer. (The air conditioner stops.)
Comes on	5-time flash	5-time flash	E 36	Over heat of compressor	Gas shortage Defective discharge pipe sensor	When discharge pipe sensor value exceeds setting value. (Compressor Stops.)
Comes on	6-time flash	6-time flash	E 5	Error or signal transmission	Defective power supply. Broken signal wire. Defective indoor/outdoor unit Circuit boards.	If serial signal cannot be sent or received for 1 minute and 55 seconds continuously.
Comes on	7-time flash	Stays on	E 48	Faulty outdoor fan motor	Defective fan motor, poor connector connection	When the outdoor unit's fan motor speed continues for 30 seconds or longer at 75 rpm or lower. (3 times) (The air conditioner stops.)
2-time flash	2-time flash	7-time flash	E 60	Compressor lock	Defective compressor Defective outdoor PCB	When the motor for the compressor does not turn 1/12 revolution 0.044 second after it has been started.
-	-	-	E 1	Error of wired remote control wiring	Broken wired remote control wire. Defective indoor unit boards	The wired remote control wire Y is open. The wired remote control wires X and Y are reversely connected. Noise is penetrating the wired remote control lines. The wired remote control or indoor control PCB is faulty. (The communications circuit is faulty.)

MULTI HEAD - SELF-DIAGNOSIS INFORMATION – Previous & Current Series

Inverter Multi Indoor		SRK	ZJ-S,ZJ-S1,ZMA-S,ZMXA-S	ZJX-S, ZJX-S1	ZK-S	
		SRR	ZJ-S, ZM-S			
Inverter Multi Outdoor		SRF	ZJX-S, ZJX-S1,ZMXA-S			
		FDTC	VD,VF, VF/1			
		FDUM	VF, VF/1, VF/2			
		FDEN	VD, VF, VF/1, VG			
Inverter Multi Outdoor		SCM	ZJ-S / ZJ-S1 / ZM-S / ZM-S1			
Indoor unit display panel		Outdoor main PCB, Red LED	Wired remote control display	Description of trouble	Cause	Display (flashing) condition
Run Light	Run Light					
1-time flash	ON	Stays off	-	Indoor heat exchanger sensor (1) error	Broken heat exchanger sensor 1 wire, poor connector connection. Indoor PCB is faulty	When a heat exchanger sensor 1 wire disconnection is detected while operation is stopped. (If a temperature of -28°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
2-time flash	ON	Stays off	-	Room temperature sensor error	Broken room temperature sensor wire, poor connection	When a room temperature sensor wire disconnection is detected while operation is stopped. (If a temperature of -45°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
3-time flash	ON	Stays off	-	Heat exchanger sensor (2) error	Broken heat exchanger sensor 2 wire, poor connector connection. Indoor PCB is faulty.	When a heat exchanger sensor 2 wire disconnection is detected while operation is stopped. (If a temperature of -28°C or lower is detected for 15 seconds, it is judged that the wire is disconnected.) (Not displayed during operation.)
4-time flash	ON	Stays off	E 9	Drain error	Defective drain pump (DM), broken drain pump wire. Anomalous float switch operation. Defective indoor PCB faulty	If the float switch OPEN is defected for 3 seconds continuously or if float switch connector or wire is disconnected.
6-time flash	ON	Stays off	E 16	Indoor fan motor error	Defective fan motor, poor connector connection	When conditions for turning the indoor unit's fan motor on exist during air-conditioner operation, an indoor unit fan motor speed of 300 (SRF:150) min-1 or lower is measured for 30 seconds or longer. (The air conditioner stops.)
Keeps Flashing	1-time flash	8-time flash	E 38	Outdoor air temperature sensor error	Broken sensor wire, poor connection, faulty outdoor PCB	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
Keeps Flashing	2-time flash	8-time flash	E 37	Outdoor heat exchanger sensor error	Broken sensor wire, poor connection, faulty outdoor PCB	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or higher is detected for within 20 seconds after power ON. (The compressor is stopped.)
Keeps Flashing	4-time flash	8-time flash	E 39	Discharge pipe sensor error	Broken sensor wire, poor connection, faulty outdoor PCB	-25°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. (The compressor is stopped.)
Keeps Flashing	5-time flash	8-time flash	E 53	Outdoor suction sensor error	Broken sensor wire, poor connection, faulty outdoor sub PCB	-55°C or lower is detected for 5 seconds continuously 3 times within 40 minutes after initial detection of this anomalous temperature. Or -55°C or higher is detected for within 20 seconds after power ON. (The compressor is stopped)
ON	1-time flash	1-time flash	E 42	Current Cut	Compressor locking, open phase on compressor output, short circuit on power transistor, closed service valve	The compressor output current exceeds the set value during compressor start. (The air-conditioner stops.)
ON	2-time flash	2-time flash	E 59	Trouble of outdoor unit	Broken compressor wire, broken power transistor, broken discharge sensor wire or poor connection, compressor blockage	When there is an emergency stop caused by trouble in the outdoor unit, or the input current value is found to be lower than the set value. (The air-conditioner stops.)
ON	3-time flash	3-time flash	E 58	Current safe stop	Overload protection, over charged, compressor locking	When the compressor command speed is lower than the set value and the current safe has operated. (the compressor stops)
ON	4-time flash	1-time flash	E 51	Power transistor error	faulty inverter PCB, faulty main PCB or faulty fan motor	When the power transistor is judged breakdown while compressor starts. (The compressor is stopped.)
ON	5-time flash	5-time flash	E 36	Over heat of compressor	Low on gas, faulty discharge pipe sensor, closed service valve	When the value of the discharge pipe sensor exceeds the set value. (The air-conditioner stops.)

Comes on	6-time flash	6-time flash	E 5	Error or signal transmission	Defective power supply, broken signal wire, faulty indoor/outdoor P.C.B.	When there is no signal between the indoor PCB and outdoor PCB for 10 seconds or longer (when the power is turned on), or when there is no signal for 7 minute 35 seconds or longer (during operation)(the compressor is stopped).
ON	7-time flash	Keeps flashing	E 48	Outdoor fan motor or main PCB	Faulty condenser fan motor or faulty main PCB	When the outdoor unit's fan motor speed continues for 30 seconds or longer at 75 min-1 or lower. (3 times) (The air conditioner stops)
ON	Keeps flashing	2-time flash	E 35	Cooling high pressure Protection	Overload protection, over charged, broken outdoor heat exchanger sensor wire, closed service valve	When the value of the outdoor heat exchanger sensor exceeds the set value
2-time flash	2-time flash	7-time flash	E 60	Rotor lock	Faulty compressor, open phase on compressor, faulty outdoor P.C.B.	If the compressor motor's magnetic pole positions cannot be correctly detected when the compressor starts. (The air-conditioner stops.)
5-time flash	ON	2-time flash	E 47	Active filter voltage error	Defective Active Filter, incorrect power supply	When the wrong voltage connected for the power source. When the outdoor main PCB is faulty
7-time flash	ON	2-time flash	E 57	Refrigerant cycle system protective control	Closed service valve, insufficient refrigerant	When refrigeration cycle system protective control operates.
-	-	1-time flash	E 41	Power transistor overheat	Faulty power transistor or sensor.	When anomalous rise of the power transistor temperature is detected 2 times within 1 hour.
-	-	2-time flash	E 40	High pressure error	Faulty high pressure sensor, faulty control PCB, poor air circulation.	When anomalous rise of the high pressure sensor is detected 5 times within 1 hour. When high pressure sensor anomaly is detected for 10 minutes continuously.
-	-	1-time flash	E 45	Outdoor main or sub PCB communication error	Outdoor sub or main PCB faulty, poor connection of wires between outdoor PCBs	Communication error for 15 minutes: Detected more than 15 seconds 4 times
-	-	8-time flash	E 54	High pressure sensor error	Faulty high pressure sensor, faulty control PCB.	If detected for 5 second continuously within 2 minutes to 2 minutes and 20 seconds after the compressor ON, the compressor stops.
-	-	-	E 1	Error of wired remote control wiring	Broken wired remote control wire Defective indoor unit boards	The wired remote control wire Y is open. The wired remote control wires X and Y are reversely connected. Noise is penetrating the wired remote control lines. The wired remote control or indoor control PCB is faulty. (The communications circuit is faulty.)
Stays off	Keeps Flashing	-	E 21	Limit switch error	Defective limit switch, air inlet panel set, I/D control PCB	Actuation of limit switch

PAC INDOOR UNIT - SELF-DIAGNOSIS INFORMATION

PAC INDOOR UNIT - SELF-DIAGNOSIS INFORMATION							
Inverter PAC Indoor unit		FDT		1, 1R, V, VD, VF, VF/1, VG			
		FDTC		1, 1R, V, VD, VF, VF/1			
		FDU		1, 1R, V, VD,			
		FDUA		VF, VF/1, VF/2, VG			
		FDUM		1, 1R, V, VD, VF, VF/1, VF/2			
		FDEN		1, 1R, V, VD, VF, VF/1, VG			
		DXU		VF, VF/1			
Remote control		Indoor control PCB		Outdoor control PCB		Location of trouble	Description of trouble
Error Code	Red LED	Red LED	Green LED (1)	Red LED	Green LED (1)		
No- indication	Stays off	Stays Off	Keeps flashing	Stays Off	Keeps flashing	Normal operation	Normal Operation
		Stays Off	Stays Off	2-time flash	Stays Off	Indoor unit power supply	Power OFF, broken wire, blown fuse, broken transformer wire
		3-time flash	Keeps flashing	Stays Off	Keeps flashing	Remote control wires	Poor connection, breakage of remote control wire. For wire breaking at power ON, the LED is OFF.
"WAIT" or INSPECT I/U		Stays Off	Keeps flashing	2-time flash	Keeps flashing	Remote control	Improper setting of master and slave by remote control
						Indoor-outdoor units connection wire	Poor connection, breakage of indoor-outdoor units connection wire
E 1		Stays Off	Keeps flashing	Stays Off	Keeps flashing	Indoor-outdoor units connection wire	Poor connection, breakage of indoor-outdoor units connection wire
						Remote control wires (Noise)	Poor connection of remote control signal wire (White). Intrusion of noise in remote control wire. For wire breaking at power ON, the LED is OFF
E 5		2-time flash	Keeps flashing	2-time flash	Keeps flashing	Remote control indoor control PCB	Defective remote control or indoor control PCB (defective communication circuit)?
						Indoor-outdoor units connection wire	Poor connection of wire between indoor-outdoor units during operation (disconnection, loose connection). Anomalous communication between indoor-outdoor units by noise, etc
						Electrical Noise	CPU Runaway on Outdoor control PCB
						Outdoor Control PCB	Occurrence of defective outdoor control PCB on the way of power source (defective communication circuit)?
E 6		1-time flash	Keeps flashing	Stays Off	Keeps flashing	Outdoor Control PCB	Defective outdoor control PCB on the way of power source
						Fuse	Blown fuse
E 7		1-time flash	Keeps flashing	Stays Off	Keeps flashing	Indoor heat exchanger temperature thermistor	Defective indoor heat exchanger temperature thermistor (defective element, broken wire, short-circuit). Poor contact of temperature thermistor connector
						Indoor control PCB	Defective indoor control PCB (Defective temperature thermistor input circuit)?
E 8		1-time flash	Keeps flashing	Stays Off	Keeps flashing	Indoor return air temperature thermistor	Defective indoor return air temperature thermistor (defective element, broken wire, short-circuit). Poor contact of temperature thermistor connector
						Installation or operating condition	Heating over-load (Anomalous high indoor heat exchanger temperature)
						Indoor heat exchanger temp sensor	Heating overload, faulty sensor, faulty indoor PCB
E 9		1-time flash	Keeps flashing	Stays Off	Keeps flashing	Indoor control PCB	Defective indoor control PCB (Defective temperature thermistor input circuit)?
						Drain trouble	Defective drain pump (DM), broken drain pump wire, disconnected connector
						Float switch	Anomalous float switch operation (malfunction)
						Option	Defective option parts (At optional anomalous input setting)
E 10		Stays Off	Keeps flashing	Stays Off	Keeps flashing	No. of connected indoor units	When multi-unit control by remote control is performed, the number of units is over 16
E 11		Keeps flashing	Keeps flashing	Stays Off	Keeps flashing	Address setting error	Address setting error of indoor units
E 14		3-time flash	Keeps flashing	Stays Off	Keeps flashing	Remote controller Fault	No master assigned to slaves, incorrect wiring, broken wire between master & slave
E 16		1(2)-time flash	Keeps flashing	Stays Off	Keeps flashing	Indoor fan motor	Faulty Indoor fan motor, poor connection, faulty indoor PCB
						Indoor power PCB	Defective indoor power PCB
E 19		1-time flash	Keeps flashing	Stays Off	Keeps flashing	Indoor control PCB	Improper operation mode setting
E 20		1-time flash	Keeps flashing	Stays Off	Keeps flashing	Fan motor	Indoor fan motor rotation speed anomaly
						Indoor power PCB	Defective indoor power PCB
E 21		Stays Off	Keeps flashing	Stays Off	Keeps flashing	Panel switch detection	Defective panel switch operation (FDT only)
E 28		Stays Off	Keeps flashing	Stays Off	Keeps flashing	Remote control temperature thermistor	Broken wire of remote control temperature thermistor

PAC OUTDOOR UNIT - SELF-DIAGNOSIS INFORMATION

Inverter PAC Outdoor		FDCVA		HEN / HENR / HENAR				
		FDC, FDCA		VN / VS / VNX / VNXA / VSX / VSA				
		DXC, DXCA		VNX / VSA				
Remote control		Indoor PCB LEDs		Outdoor unit LEDs		INV LED	Location of trouble	Description of trouble
Error Code	Red LED	Red LED	Green LED (1)	Red LED	Green LED (1)	Yellow LED		
E 33		Stays off	Keeps flashing	1-time flash	Keeps flashing	-	Power supply	Anomalous current on inverter primary side
E 34		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Power supply	Phase open circuit, faulty outdoor control PCB (3 Phase model)
E 35		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Installation or operating condition	Higher outdoor heat exchanger temperature
							Outdoor heat exchanger temperature thermistor	Defective outdoor heat exchanger temperature thermistor
							Outdoor control PCB	Defective outdoor control PCB (Defective temperature thermistor input circuit)?
E 36		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Installation or operating condition	Higher discharge temperature
							Discharge pipe temperature thermistor	Defective discharge pipe temperature thermistor
							Outdoor control PCB	Defective outdoor control PCB (Defective temperature thermistor input circuit)?
E 37		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Outdoor heat exchanger thermistor	Defective outdoor heat exchanger temperature thermistor, broken wire or poor connector connection
							Outdoor control PCB	Defective outdoor control PCB (Defective temperature thermistor input circuit)?
E 38		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Outdoor air temperature thermistor	Defective outdoor air temperature thermistor, broken wire or poor connector connection
							Outdoor control PCB	Defective outdoor control PCB (Defective temperature thermistor input circuit)?
E 39		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Discharge pipe temperature thermistor	Defective discharge pipe temperature thermistor, broken wire or poor connector connection
							Outdoor control PCB	Defective outdoor control PCB (Defective temperature thermistor input circuit)?
E 40		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Installation or operating condition	Rising high pressure (Operation of 63H1) • Service valve closing operation
							Outdoor control PCB	Defective outdoor control PCB (Defective 63H input circuit)?
E 41		Stays off	Keeps flashing	1-time flash	Keeps flashing	2- or 6-time flash	Inverter PCB or radiator fin	Power transistor overheat
E 42		Stays off	Keeps flashing	1-time flash	Keeps flashing	1- or 5-time flash	Outdoor control PCB compressor	Current cut (Anomalous compressor over-current)
							Installation or operating condition	Service valve closing operation
E 45		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Outdoor control PCB	Anomalous outdoor control PCB communication
							Inverter PCB	Anomalous inverter PCB communication
E 47		Stays off	Keeps flashing	1-time flash	Keeps flashing	7-time flash	Control PCB, Power transistor	Anomalous inverter over voltage
E 48		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Outdoor fan motor	Anomalous outdoor fan motor
							Outdoor control PCB	Defective outdoor control PCB (Defective motor input circuit)?
E 49		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Installation or operating condition	Low pressure error • Service valve closing operation
							Low pressure sensor	Anomalous low pressure, broken wire of low pressure sensor or poor connector connection
							Outdoor control PCB	Defective outdoor control PCB (Defective sensor input circuit)?
E 51		Stays off	Keeps flashing	1-time flash	Keeps flashing	2- or 6-time flash	Inverter PCB	Anomalous inverter PCB
							Suction pipe temperature thermistor	Defective suction pipe temperature thermistor, broken wire or poor connector connection
E 53		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Outdoor control PCB	Defective outdoor PCB (Defective thermistor input circuit)?
							Low Pressure Sensor Error	Defective low pressure sensor
E 54		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Outdoor control PCB	Defective outdoor control PCB (Defective sensor input circuit)?
							Under-dome temp thermistor	Poor connection, broken wire, faulty thermistor, faulty PCB
E 57		Stays off	Keeps flashing	1-time flash	Keeps flashing	Keeps flashing	Operation status	Shortage in refrigerant quantity
							Installation status	Service valve closing operation
E 59		Stays off	Keeps flashing	5-time flash	Keeps flashing	Stays off or 4-times flash	Compressor inverter PCB	Anomalous compressor start-up
E 60		Stays off	Keeps flashing	1-time flash	Keeps flashing	-	Compressor	Faulty compressor, faulty inverter circuit.
E 75		Stays off	Keeps flashing	Off	Keeps flashing	-	Central Controller communication error	Poor connection, broken wire, faulty controller

PAC INDOOR UNIT WITH RAC OUTDOOR UNIT - SELF-DIAGNOSIS INFORMATION

Inverter PAC Indoor/Outdoor		FDT		50,60VF/VG		
		FDTC		VF		
		FDUM		VF		
		SRC		ZHX-S / ZIX-S / ZJX-S / ZMXA-S / ZSXA-W		
Remote control		Indoor control PCB		Outdoor Control PCB	Location of trouble	Description of trouble
Error Code	Red LED	Red LED	Green LED	Red LED		
E 35		Stays off	Keeps flashing	2-time flash	Installation, operation status	Higher outdoor heat exchanger temperature
					Outdoor heat exchanger temp sensor	Defective outdoor heat exchanger temperature sensor
					Outdoor control PCB	Defective outdoor control PCB (Defective temperature sensor input circuit)?
E 36		Stays off	Keeps flashing	5-time flash	Installation, operation status	Higher discharge temperature
					Discharge pipe temperature sensor	Defective discharge pipe temperature sensor
					Outdoor control PCB	Defective outdoor control PCB (Defective temperature sensor input circuit)?
E 37		Stays off	Keeps flashing	8-time flash	Outdoor heat exchanger temperature sensor	Defective outdoor heat exchanger temperature sensor, broken wire or poor connector connection
					Outdoor control PCB	Defective outdoor control PCB (Defective temperature sensor input circuit)?
E 38		Stays off	Keeps flashing	8-time flash	Outdoor air temperature sensor	Defective outdoor air temperature sensor, broken wire or poor connector connection
					Outdoor control PCB	Defective outdoor control PCB (Defective temperature sensor input circuit)?
E 39		Stays off	Keeps flashing	8-time flash	Discharge pipe temperature sensor	Defective discharge pipe temperature sensor, broken wire or poor connector connection
					Outdoor control PCB	Defective outdoor control PCB (Defective temperature sensor input circuit)?
E 40	Keeps Flashing	Stays off	Keeps flashing	4-time flash	Installation, operation status	Service valve (gas side) closing operation
E 42		Stays off	Keeps flashing	2-time flash	Outdoor control PCB, compressor	Current cut (Anomalous compressor over-current)
					Installation, operation status	Service valve closing operation
E 47		Stays off	Keeps flashing	2-time flash	Outdoor control PCB	Defective active filter
E 48		Stays off	Keeps flashing	Keeps flashing	Fan motor	Defective fan motor
					Outdoor control PCB	Defective outdoor control PCB
E 51		Stays off	Keeps flashing	1-time flash	Power transistor, outdoor control PCB	Power transistor error
E 57		Stays off	Keeps flashing	2-time flash	Operation status	Shortage in refrigerant quantity
					Installation status	Service valve closing operation
E 58		Stays off	Keeps flashing	3-time flash	Overload operation, overcharge, compressor locking	Current safe stop
E 59		Stays off	Keeps flashing	2-time flash	Compressor, outdoor control PCB	Anomalous compressor start up
E 60		Stays off	Keeps flashing	7-time flash	Compressor	Anomalous compressor rotor lock



KX SELF-DIAGNOSIS INFORMATION							
Inverter KX		LED Display				FDCA----HKXE4_HXKRE4. FDC----KXEN6, KXE6, KXRE6, KXZE1, KXZPE1, KXZRE1	
		Indoor control PCB		Outdoor Control PCB			
Error Code	O/D 7 segment display	Green LED	Red LED	Green LED	Red LED	Location of Trouble	Presumable Causes
E1		keeps flashing	stays off	keeps flashing	stays off	Communication error (indoor-remote control)	Poor or wrong connection, broken wire, intrusion of noise, faulty indoor PCB or remote control
E2		keeps flashing	keeps flashing	keeps flashing	stays off	Duplicated indoor unit address	Number of connected indoor units exceeds the limitation, duplicated indoor unit address, indoor control PWB anomaly.
E3		keeps flashing	2 time flash	keeps flashing	stays off	Outdoor unit signal line error	Power not supplied to the O/D unit, mismatch of pairing between I/D and O/D units, indoor control PWB anomaly, Outdoor control PWB anomaly, Missing local wiring.
E5		keeps flashing	2 time flash or stays off	keeps flashing	2 time flash	Communication error during operation	Unit address number setting error, remote control wires broken, poor connection/disconnection of remote control wires, indoor control PWB anomaly
E6		keeps flashing	1 time flash	keeps flashing	stays off	Indoor heat exchanger thermistor anomaly	Anomalous connection of I/D heat exchanger temperature thermistor, I/D heat exchanger thermistor anomaly, I/D control PWB anomaly
E7		keeps flashing	1 time flash	keeps flashing	stays off	Indoor return air temperature thermistor anomaly	Anomalous connection of I/D return air temperature thermistor, I/D return air thermistor anomaly, I/D control PWB anomaly
E9		keeps flashing	1 time flash	keeps flashing	stays off	Drainage trouble	I/D control PWB anomaly, Mistake in setting of float switch, mistake in setting of optional equipment, mistake in drain piping, drain motor anomaly, disconnection/breakage of drain motor wires
E10		keeps flashing	stays off	keeps flashing	stays off	Excessive number of indoor units (more than 17 units) by controlling one remote control	Excessive number of I/D units, remote control anomaly
E11		keeps flashing	stays off	keeps flashing	stays off	Address setting error between master and slave indoor units	IU address has been set using the "Master IU address set" function of remote control
E12		keeps flashing	keeps flashing	keeps flashing	stays off	Address setting error by mixed setting method	Automatic address setting and manual address setting method are mixed when setting address of indoor units
E16		keeps flashing	1 time flash	keeps flashing	stays off	Indoor fan motor anomaly (FDT, FDTC, FDTW, FDTS, FDU, FDUM, FDK, FDUT71, FDFW series)	I/D fan motor anomaly, foreign matter at rotational area of fan propeller, fan motor anomaly, dust on control PWB, blown fuse, external noise, surge
E18		keeps flashing	1 time flash	keeps flashing	stays off	Address setting error of master and slave indoor units	Address setting error of the master indoor unit, no power to the master indoor unit, no connection of super link signal wires between master and slave indoor unit
E19		keeps flashing	1 time flash	keeps flashing	stays off	Indoor unit operation check drain motor check mode anomaly	Mistake in SW7-1 setting due to forgetting to turn off SW7-1 after indoor operation check
E20		keeps flashing	1 time flash	keeps flashing	stays off	Indoor fan motor speed anomaly (FDT, FDTC, FDTW, FDTS, FDU, FDUM, FDK, FDUT71, FDFW series)	I/D fan motor anomaly, foreign matter at rotational area of fan propeller, fan motor anomaly, dust on control PWB, blown fuse, external noise, surge
E21		keeps flashing	1 time flash	keeps flashing	stays off	Defective panel switch operation (FDT)	Defective panel switch, disconnection of wiring, defective I/D control PWB
E28		keeps flashing	stays off	keeps flashing	stays off	Remote control temperature thermistor anomaly (Thc)	Anomalous connection of remote control temperature thermistor, remote control temperature thermistor anomaly, remote control PWB anomaly
E31		keeps flashing	stays off	keeps flashing	1 time flash	Duplicated outdoor unit address number	Mistake in address setting of outdoor units, more than 129 I/D units connected, no setting of master/slave setting switch for combination use

E32		keeps flashing	stays off	keeps flashing	2 time flash	Open L3 phase on power supply at primary side	Anomalous power supply at primary side, outdoor control PWB anomaly
E36	E36-1	keeps flashing	stays off	keeps flashing	1 time flash	Discharge pipe temperature error, Tho-D1	Discharge pipe temperature anomaly, SV1,2 anomaly, breakage in coil, faulty main body, O/D control PWB anomaly, insufficient amount of refrigerant, insufficient airflow volume, short circuit of airflow
	E36-2	keeps flashing	stays off	keeps flashing	2 time flash	Discharge pipe temperature error, Tho-D2	
	E36-3	keeps flashing	stays off	keeps flashing	3 time flash	Liquid flooding anomaly	KX6 product only
E37	E37-1	keeps flashing	stays off	keeps flashing	1 time flash	Outdoor heat exchanger temperature thermistor anomaly, Tho-R1	Broken thermistor harness or the internal wire of sensing section, disconnection of thermistor harness connection, O/D control PWB anomaly
	E37-2	keeps flashing	stays off	keeps flashing	2 time flash	Outdoor heat exchanger temperature thermistor anomaly, Tho-R2	
	E37-3	keeps flashing	stays off	keeps flashing	3 time flash	Outdoor heat exchanger temperature thermistor anomaly, Tho-R3	
	E37-4	keeps flashing	stays off	keeps flashing	4 time flash	Outdoor heat exchanger temperature thermistor anomaly, Tho-R4	
	E37-5	keeps flashing	stays off	keeps flashing	5 time flash	Outdoor sub cooling coil temperature thermistor 1 anomaly, Tho-SC	
	E37-6	keeps flashing	stays off	keeps flashing	6 time flash	Outdoor sub cooling coil temperature thermistor 2 anomaly, Tho-H	
E38		keeps flashing	stays off	keeps flashing	1 time flash	Outdoor air temperature thermistor anomaly, Tho-A	
E39	E39-1	keeps flashing	stays off	keeps flashing	1 time flash	Discharge pipe temperature thermistor anomaly, Tho-D1	
	E39-2	keeps flashing	stays off	keeps flashing	2 time flash	Discharge pipe temperature thermistor anomaly, Tho-D2	
E40		keeps flashing	stays off	keeps flashing	1 time flash	High Pressure anomaly, 63H1-1, 2 activated	Short circuit of airflow at condenser side of heat exchanger/disturbance of airflow/clogging filter/fan motor anomaly, disconnection of high pressure switch connector, breakage of high pressure switch harness, closed service valves, high pressure sensor anomaly, high pressure switch anomaly
E41	E41-1	keeps flashing	stays off	keeps flashing	1 time flash	Power transistor overheat, CM1	Anomalous high temperature of power transistor is detected 5 times within 60 minutes. Power transistor anomaly, power transistor temperature thermistor anomaly, inverter PWB anomaly, outdoor fan motor anomaly, anomalous cooling fan motor for inverter
	E41-2	keeps flashing	stays off	keeps flashing	2 time flash	Power transistor overheat, CM2	
E42	E42-1	keeps flashing	stays off	keeps flashing	1 time flash	Current cut, CM1	Compressor anomaly, refrigerant leak, power transistor module anomaly, anomalous power supply for INV PWB, O/D fan motor anomaly
	E42-2	keeps flashing	stays off	keeps flashing	2 time flash	Current cut, CM2	
E43	E43-1	keeps flashing	stays off	keeps flashing	1 time flash	Excessive number of indoor units connected	Mistake in setting of I/D or O/D addresses, mistake in signal wire connection
	E43-2	keeps flashing	stays off	keeps flashing	2 time flash	Excessive total capacity of connection	
E44	E44-1	keeps flashing	stays off	keeps flashing	1 time flash	Liquid flooding anomaly, CM1	KXZ Product only. Mismatching of refrigerant piping and or signal wiring, overcharging of refrigerant, anomalous control of superheat, anomalous circuit of liquid refrigerant by-pass, anomalous refrigerant circuit of sub cooling coil, under dome temperature Tho-D1, D2 anomaly
	E44-2	keeps flashing	stays off	keeps flashing	2 time flash	Liquid flooding anomaly, CM2	


E45	E45-1	keeps flashing	stays off	keeps flashing	1 time flash	Communication error between inverter PWB and outdoor control PWB, INV 1	Signal wire anomaly, O/D control PWB anomaly, INV PWB anomaly, inrush current prevention resistor anomaly, defective 52C or 52X, defective diode module
	E45-2	keeps flashing	stays off	keeps flashing	2 time flash	Communication error between inverter PWB and outdoor control PWB, INV 2	
E46		keeps flashing	stays off	keeps flashing	stays off	Mixed address setting methods coexist in the same network	Mistake in the address setting, mistake in the connection of signal wire
E48	E48-1	keeps flashing	stays off	keeps flashing	1 time flash	Outdoor DC fan motor anomaly, FMO1	Broken or disconnected wire, faulty fan motor, defective inverter PWB, defective control PWB, defective power transistor, defective diode module, defective surge suppressor resistor
	E48-2	keeps flashing	stays off	keeps flashing	2 time flash	Outdoor DC fan motor anomaly, FMO2	
E49		keeps flashing	stays off	keeps flashing	1 time flash	Low pressure anomaly	Low pressure sensor (PSL) anomaly, service valves closed, EEV anomaly, insufficient refrigerant amount, clogging at EEV or strainer
E51	E51-1	keeps flashing	stays off	keeps flashing	1 time flash	Power transistor overheat, CM1	Anomalous high temperature of power transistor is detected 15 minutes continuously. Broken thermistor harness or the internal wire of sensing section, disconnection of thermistor harness connection, O/D control PWB anomaly
	E51-2	keeps flashing	stays off	keeps flashing	2 time flash	Power transistor overheat, CM2	
E53	E53-1	keeps flashing	stays off	keeps flashing	1 time flash	Suction pipe temperature thermistor anomaly, Tho-S, CM1	Broken thermistor harness or the internal wire of sensing section, disconnection of thermistor harness connection, O/D control PWB anomaly
	E53-2	keeps flashing	stays off	keeps flashing	2 time flash	Suction pipe temperature thermistor anomaly, Tho-S, CM2	
E54	E54-1	keeps flashing	stays off	keeps flashing	1 time flash	Low pressure anomaly (PSL)	Broken sensor harness, disconnection of sensor harness connection, sensor (PSH, PSL) anomaly, O/D control PWB anomaly, anomalous installation conditions, insufficient airflow volume, excessive or insufficient refrigerant amount
	E54-2	keeps flashing	stays off	keeps flashing	2 time flash	High pressure anomaly (PSH)	
E55	E55-1	keeps flashing	stays off	keeps flashing	1 time flash	Under dome temperature thermistor anomaly, Tho-C1	Broken thermistor harness or the internal wire of sensing section, disconnection of thermistor harness connection, O/D control PWB anomaly
	E55-2	keeps flashing	stays off	keeps flashing	2 time flash	Under dome temperature thermistor anomaly, Tho-C2	
E56	E56-1	keeps flashing	stays off	keeps flashing	1 time flash	Power transistor temperature anomaly, Tho-P1	Broken thermistor harness or the internal wire of sensing section, disconnection of thermistor harness connection, O/D control PWB anomaly
	E56-2	keeps flashing	stays off	keeps flashing	2 time flash	Power transistor temperature anomaly, Tho-P2	
E58	E58-1	keeps flashing	stays off	keeps flashing	1 time flash	Anomalous compressor by loss of synchronism, CM1	Insufficient time elapsed after the power supplied before compressor start up (unit started without crankcase heater ON), compressor anomaly, inverter PWB anomaly, power transistor anomaly
	E58-2	keeps flashing	stays off	keeps flashing	2 time flash	Anomalous compressor by loss of synchronism, CM2	
E59	E59-1	keeps flashing	stays off	keeps flashing	1 time flash	Compressor start up failure, CM1	Anomalous voltage of power supply, anomalous components for refrigerant circuit, inverter PWB anomaly, loose connection of connector or cable, compressor anomaly (motor or bearing)
	E59-2	keeps flashing	stays off	keeps flashing	2 time flash	Compressor start up failure, CM2	
E60	E60-1	Keeps flashing	Stays off	Keeps flashing	1 time flash	Rotor position detection error, CM1	KX4 & KX6 Product. If it fails to detect the rotor position of compressor, after changing over to the operation of compressor rotor position detection, the compressor stops. It restarts automatically after 3 minutes delay. If this anomaly occurs 4 times within 15 minutes after the initial detection, error is displayed
	E60-2	Keeps flashing	Stays off	Keeps flashing	2 time flash	Rotor position detection error, CM2	
E61	E61-1	keeps flashing	Stays off	keeps flashing	1 time flash	Communication error between the master unit and slave units, Slave unit 1	Signal wire anomaly, O/D control PWB anomaly, INV PWB anomaly, inrush current prevention resistor anomaly
	E61-2	keeps flashing	Stays off	keeps flashing	2 time flash	Communication error between the master unit and slave units, Slave unit 2	
E63		keeps flashing	Stays off	keeps flashing	1 time flash	Emergency stop. When an ON signal is inputted to the CNT terminal of I/D control PWB	Factor for emergency stop
E75		keeps flashing	Stays off	keeps flashing	stays off	Central control communications error	Poor connection, broken wire, faulty controller

Test Procedure – 1PH & 3PH Diode Module


“WARNING” Power off the unit, waiting a minimum 3 minutes before removing any applicable wiring. Ensure to measure that the DC voltage has discharged sufficiently before carrying out the below testing.



Test No:	Tester (+) (Red)	Tester (-) (Black)	Result With Multimeter (Resistance)	Result with Diode Tester (Buzzer)
1	1	4	Several Megohms	On
2	2	4	Several Megohms	On
3	5	1	Several Megohms	On
4	5	2	Several Megohms	On
5	4	1	Several 10 Megohms	Off
6	4	2	Several 10 Megohms	Off
7	1	5	Several 10 Megohms	Off
8	2	5	Several 10 Megohms	Off



Outlook of diode module



Inner circuit of diode module

Measure the resistance the point (No. 1-12) shown in following table by circuit tester. ①-⑤ are the terminal No. shown in the above drawing.

No.	Tester (+) (Red)	Tester (-) (Black)	Resistance (ohm)	Remarks
1	①	④	several MΩ	Upper arm U in normal direction
2	②	④	several MΩ	Upper arm V in normal direction
3	③	④	several MΩ	Upper arm W in normal direction
4	⑤	①	several MΩ	Lower arm U in normal direction
5	⑤	②	several MΩ	Lower arm V in normal direction
6	⑤	③	several MΩ	Lower arm W in normal direction
7	④	①	several 10MΩ	Upper arm U in reverse direction
8	④	②	several 10MΩ	Upper arm V in reverse direction
9	④	③	several 10MΩ	Upper arm W in reverse direction
10	①	⑤	several 10MΩ	Lower arm U in reverse direction
11	②	⑤	several 10MΩ	Lower arm V in reverse direction
12	③	⑤	several 10MΩ	Lower arm W in reverse direction


<Judgement>

- i) If the resistance is 0-several k ohm, diode module could be burnt.
- ii) If the resistance is infinitive (∞), diode module could be burnt either.

※In case that the judgement is i) or ii), diode module should be replaced.

Test Procedure – 3 PH Transistor Module

“WARNING” Power off the unit, waiting a minimum 3 minutes before removing any applicable wiring. Ensure to measure that the DC voltage has discharged sufficiently before carrying out the below testing.



Measure the resistance the point shown in following table by circuit tester. **P, N, U, V and W** are the terminal No. shown in the above drawing.

Tester (+) Red	Tester (-) Black	Resistance (Ohm)
P	N	OL / Several 10MΩ
N	P	Several MΩ
P	U	OL Several 10MΩ
	V	
	W	
N	U	Several 100kΩ
	V	
	W	
U	P	Several 100kΩ
V		
W		
U	N	OL Several 10MΩ
V		
W		

<Judgement>



If the measured values range from 0 ~ a few kΩ, there is a possibility that the elements are damaged, so replace the power transistor parts.

Test Procedure – Electronic Expansion Valve

“WARNING” Power off the unit, waiting a minimum 3 minutes before removing any applicable wiring. Ensure to measure that DC voltage has discharged sufficiently before carrying out the below testing.


Measure the resistance points as per the following table by Multimeter.

If readings are within the nominated table values, it is normal.



From	To	Reference Resistance	Old	New
White	Red	45 - 50 ohms	Yes	Yes
Red	Orange	45 - 50 ohms	Yes	Yes
Orange	White	90 - 100 ohms	Yes	Yes
Yellow	Brown	45 - 50 ohms	Yes	not applicable
Brown	Blue	45 - 50 ohms	Yes	not applicable
Blue	Yellow	90 - 100 ohms	Yes	Yes
Yellow	Red	45 - 50 ohms	not applicable	Yes
Red	Blue	45 - 50 ohms	not applicable	Yes
Blue	Yellow	90 - 100 ohms	not applicable	Yes

DC FAN MOTOR TESTING





Expected Readings of Control PWB VDC Outputs to DCFM			Expected Readings of DC Fan Motor Circuit Board Resistances		
Multi Meter Test Points for VDC			Multi Meter Test Points for Ω		
Multimeter Red Probe	Multimeter Black Probe	PCB DC Volts	Multimeter Black Probe	Multimeter Red Probe	DCFM PWB Resistance Value
Vm	Gnd	# 300 ~ 350 Vdc	Vm	Gnd	# > 1 MΩ
Vcc	Gnd	# 15 Vdc	Vcc	Gnd	# > 1 KΩ
Vsp	Gnd	* 2 ~ 7 Vdc	Vsp	Gnd	# > 100 KΩ
Vfg	Gnd	* 2 ~ 7 Vdc	Vfg	Gnd	
* All Series – Voltages are only present during operation.			# If Resistance Values are ok, confirm with DCFM Tester.		
# ZM Series onwards - Voltages are only present during operation.			Note: If no resistance value is evident, reverse multimeter probes and re-test.		

Wiring of DC Fan Motor		DC Fan Motor Type		
		Type A	Type B / C	Type D
Vm	Motor Power Voltage Input	Red	Red	Red
Gnd	Ground	Black	Blue	Black
Vcc	Control Power Voltage Input	White	Brown	White
Vsp	Speed Control Voltage Input	Yellow	Orange	Yellow
Vfg	Revolution Pulse Output	Blue	White	Blue




IMPORTANT NOTE: The current version of the DCFM Tool, Part No: RMA006A012A (short/wide model) can run/test the Type C fan motor. The original version of the DCFM Tool, Part No: RMA006A012 (long/narrow model) cannot run/test the Type C fan motor.

DC FAN MOTOR TESTING



Type "A" Fan Motor



Type "B / C" Fan Motor



Type 'D' Fan Motor



Subject : Outdoor DC Fan Motor


Connection Table of Power Lead Wires

No.	Color code	
1	RED	V _m
2	BLACK	GND

Connection Table of Sensor Lead Wires

No.	Color code	
1	WHITE	V _{cc}
2	ORANGE	REV
3	YELLOW	VSP
4	BLUE	FG
5	GREEN	OVERC
6	PINK	GND

OUTLINE OF THE DRIVER CIRCUIT



Measure the resistance

Measure point	Tester (+) Red	Tester (-) Black	Resistance (Ohm)	Tester (-) Black	Tester (+) Red	Resistance (Ohm)
V _m - GND	Red	Black	several ten MΩ	Black	Red	several MΩ
V _{cc} - GND	White	Pink	several kΩ	Pink	White	several kΩ
V _{sp} - GND	Yellow	Pink	several hundred kΩ	Pink	Yellow	several hundred kΩ
FG - GND	Blue	Pink	OL	Pink	Blue	several ten MΩ
V _m - V _{cc}	Red	White	several ten MΩ	White	Red	several MΩ
V _m - V _{sp}	Red	Yellow	several ten MΩ	Yellow	Red	several MΩ
V _m - FG	Red	Blue	OL	Blue	Red	OL
V _{cc} - V _{sp}	White	Yellow	several hundred kΩ	Yellow	White	several hundred kΩ
V _{cc} - FG	White	Blue	several ten MΩ	Blue	White	OL
V _{sp} - FG	Yellow	Blue	several ten MΩ	Blue	Yellow	OL

Note:
 V_m : DC 15 V output
 REV : Reverse turn detection output
 V_{sp} : Speed command output
 FG : RPM monitor input
 OverC: Over - current error input

THERMISTOR TEMPERATURE & RESISTANCE CHARACTERISTICS


O/D Heat Exchanger [Tho-R1,R2,R3,R4]

I/D Heat Exchanger [Thi-R1,R2,R3]

Outside Air [Tho-A] RAC Product

Suction Pipe [Tho-S, Tho-H]

Return Air [Thi-A]




Wall Controller [ThC]


Temperature (°C)	Resistance value (kΩ)	Temperature (°C)	Resistance value (kΩ)
0	65	30	16
1	62	32	15
2	59	34	14
4	53	36	13
6	48	38	12
8	44	40	11
10	40	42	9.9
12	36	44	9.2
14	33	46	8.5
16	30	48	7.8
18	27	50	7.3
20	25	52	6.7
22	23	54	6.3
24	21	56	5.8
26	19	58	5.4
28	18	60	5

Discharge Pipe [Tho-D]

Power Transistor [Tho-P]




Outdoor Air [Tho-A] PAC Product



Hi-Wall Mounted Inverter Split Systems - SERVICE MODE – SRK / DXK (R410A Models only)


Term	Explanation
Service Mode	The service mode is the mode where service data are displayed by flashing lights when the operations described below are performed with the indoor controller
Service Data	These are the contents of error displays and protective stops which occurred in the past in the system. Error display contents and protective stop data from past anomalous operations are saved in the indoor unit controller's non-volatile memory. There are two types of data, self-diagnosis data and stop data.
Self-Diagnosis Data (Error code)	These are the data which display error display (self-diagnosis display) occurred in an indoor unit. Data are recorded for up to 5 previous occurrences. Data which is older than the 5th previous occurrence are erased. In addition, data on the temperature of each sensor are recorded when trouble occurs, so more detailed information can be checked.
Stop Data (Stop code)	These are the data which display the reason by which a stop occurred when the system performed protective stops, etc. in the past. If stop data alone are generated, the system restarts automatically. Data older than the 10th previous occasion are erased. (Important) In cases where transient stop data only are generated, the system may still be normal. However, if the same protective stop occurs frequently (3 or more times), it could lead to customer complaints

Service mode display procedure



*3: To Count the number of flashes in the service mode, count the number of flashes after the light lights up for 1.5 sec initially (start signal). Do not count start signal.

- In the case of current cut (example: stop code "42")
 The RUN light (10's digit) flashes 4 times and the TIMER light (1's digit) flashes 2 times.
 $4 \times 10 + 2 \times 10 = 42$ > from the table, read the instructions for error code 42, "current cut".



*4: When in the service mode, when the remote control settings (operation switching, fan speed switching, temperature setting) are set as shown in the following table and sent to the air conditioner unit, the unit switches to display of service data.

SELF-DIAGNOSTIC DATA		
Wireless Remote Control Setting		Contents of Output Data
Operation Mode	Fan Speed	
Cooling	MED	Displays the reason for stopping display in the past (error code)
	HI	Displays the room temp sensor reading at the time the error code was displayed in the past
	AUTO	Displays indoor heat exchanger sensor temp at the time the error code was displayed in the past
Heating	LO	Displays the remote control information at the time the error code was displayed in the past
	MED	Displays the outdoor air temp sensor reading at the time the error code was displayed in the past
	HI	Displays the outdoor heat exchanger sensor temp at the time the error code was displayed in the past
	AUTO	Displays the discharge pipe sensor temp at the time the error code was displayed in the past

Wireless remote control	Indicates the number of occasions previous to the present the error display data are from
Temperature setting	
21°C	Previous time
22°C	2nd previous time
23°C	3rd previous time
24°C	4th previous time
25°C	5th previous time

Only for models that have Indoor Heat Exchanger 2	
Wireless Remote Control	Indicates the number of occasions previous to the present the error display data are from
Temperature setting	
26°C	Previous time
27°C	2nd previous time
28°C	3rd previous time
29°C	4th previous time
30°C	5th previous time

(Example)

Wireless Remote Control Setting			Displayed Data
Operation Switching	Fan Speed Switching	Temp Setting	
Cooling	Medium	21°C	Displays the reason for the stop the previous time an error code was displayed
		22°C	Displays the reason for the stop 2 times previous time an error was displayed
		23°C	Displays the reason for the stop 3 times previous time an error was displayed
		24°C	Displays the reason for the stop 4 times previous time an error was displayed
		25°C	Displays the reason for the stop 5 times previous time an error was displayed

(ii) Stop data

Remote Control Setting			Displayed Data
Operation Switching	Fan Speed Switching	Temp Setting	
Cooling	LO	21°C	Displays the reason for the (stop code) the previous time when the A/C was stopped by protective stop control
		22°C	Displays the reason for the (stop code) 2 times previous when the A/C was stopped by protective stop control
		23°C	Displays the reason for the (stop code) 3 times previous when the A/C was stopped by protective stop control
		24°C	Displays the reason for the (stop code) 4 times previous when the A/C was stopped by protective stop control
		25°C	Displays the reason for the (stop code) 5 times previous when the A/C was stopped by protective stop control
		26°C	Displays the reason for the (stop code) 6 times previous when the A/C was stopped by protective stop control
		27°C	Displays the reason for the (stop code) 7 times previous when the A/C was stopped by protective stop control
		28°C	Displays the reason for the (stop code) 8 times previous when the A/C was stopped by protective stop control
		29°C	Displays the reason for the (stop code) 9 times previous when the A/C was stopped by protective stop control
		30°C	Displays the reason for the (stop code) 10 times previous when the A/C was stopped by protective stop control

(d) Operation mode, Fan speed mode information tables

(i) Operation mode

Display pattern when in Service Mode	Operation switching when there is an abnormal stop
RUN light (10's digit)	
--	AUTO
1 time flash	DRY
2 time flash	COOL
3 time flash	FAN
4 time flash	HEAT


(ii) Fan Speed mode

Display pattern when in Service Mode	Fan Speed mode when there is an abnormal stop
TIMER light (1's digit)	
--	AUTO
2 time flash	HI
3 time flash	MED
4 time flash	LO
5 time flash	ULO
6 time flash	HI POWER
7 time flash	ECONO

* If no data is recorded (error code is normal), the information display in the operation mode and fan speed mode becomes as follows;

Mode	Display when error code is normal
Operation mode	Auto
Fan speed mode	Auto

(Example): Operation mode: COOL, Fan speed mode: HI



(e) Temperature information

- (i) Room temperature sensor, indoor heat exchanger sensor, outdoor air temperature sensor, outdoor heat exchanger sensor temperature

Unit: °C

RUN light (10's digit) / Buzzer sound		TIMER light (1's digit)									
		0	1	2	3	4	5	6	7	8	9
Yes (sounds for 0.1 second)	6	-60	-61	-62	-63	-64					
	5	-50	-51	-52	-53	-54	-55	-56	-57	-58	-59
	4	-40	-41	-42	-43	-44	-45	-46	-47	-48	-49
	3	-30	-31	-32	-33	-34	-35	-36	-37	-38	-39
	2	-20	-21	-22	-23	-24	-25	-26	-27	-28	-29
	1	-10	-11	-12	-13	-14	-15	-16	-17	-18	-19
	0		-1	-2	-3	-4	-5	-6	-7	-8	-9
No (does not sound)	0	0	1	2	3	4	5	6	7	8	9
	1	10	11	12	13	14	15	16	17	18	19
	2	20	21	22	23	24	25	26	27	28	29
	3	30	31	32	33	34	35	36	37	38	39
	4	40	41	42	43	44	45	46	47	48	49
	5	50	51	52	53	54	55	56	57	58	59
	6	60	61	62	63	64	65	66	67	68	69
	7	70	71	72	73	74	75	76	77	78	79
	8	80	81	82	83	84	85	86	87	88	89
	9	90	91	92	93	94	95	96	97	98	99


*If no data are recorded (error code is normal), the information display in the remote control becomes as follows.

Sensor name	Sensor value displayed when the error code is normal
Room temperature sensor	-64°C
Indoor heat exchanger sensor	-64°C
Outdoor air temperature sensor	-64°C
Outdoor heat exchanger sensor	-64°C
Discharge pipe sensor	-64°C

EXAMPLE - Outdoor air sensor temperature "42 °C"

If the temperature is ≥ 0 , the buzzer does not sound.

Run light x4, Timer light x 2.



No Buzzer, Run light x 4, Timer light x 2

(ii) Discharge pipe sensor temperature

		Unit: °C										
		TIMER light (1's digit)										
Buzzer sound		0	1	2	3	4	5	6	7	8	9	
RUN light (10's digit)												
Yes (sounds for 0.1 second)	3	-60	-62	-64								
	2	-40	-42	-44	-46	-48	-50	-52	-54	-56	-58	
	1	-20	-22	-24	-26	-28	-30	-32	-34	-36	-38	
	0	-	-2	-4	-6	-8	-10	-12	-14	-16	-18	
No (does not sound)	0	0	2	4	6	8	10	12	14	16	18	
	1	20	22	24	26	28	30	32	34	36	38	
	2	40	42	44	46	48	50	52	54	56	58	
	3	60	62	64	66	68	70	72	74	76	78	
	4	80	82	84	86	88	90	92	94	96	98	
	5	100	102	104	106	108	110	112	114	116	118	
	6	120	122	124	126	128	130	132	134	136	138	
	7	140	142	144	146	148	150					

*If no data are recorded (error code is normal), the information display in the remote control becomes as follows.

Sensor name	Sensor value displayed when the error code is normal
Discharge pipe sensor	-64°C

SERVICE DATA RECORD FORM

Customer		Model number					
Date of Investigation		Serial number					
Content of Complaint							
Remote Control Settings			Content of displayed data	Display results			Display content
Temp setting	Operation switching	Fan speed switching		Buzzer Yes/No	RUN light (Times)	TIMER light (Times)	
21	Cooling	MED	Error code on previous occasion	/			
		HI	Room temperature sensor on previous occasion				
		AUTO	Indoor heat exchanger sensor 1 on previous occasion				
	Heating	LO	Remote control information on previous occasion	/			
		MED	Outdoor air temperature sensor on previous occasion				
		HI	Outdoor heat exchanger sensor on previous occasion				
	AUTO	Discharge pipe sensor on previous occasion					
26	Cooling	AUTO	Indoor heat exchanger sensor 2 on previous occasion				
22	Cooling	MED	Error code on 2nd previous occasion	/			
		HI	Room temperature sensor on 2nd previous occasion				
		AUTO	Indoor heat exchanger sensor 1 on 2nd previous occasion				
	Heating	LO	Remote control information on 2nd previous occasion	/			
		MED	Outdoor air temperature sensor on 2nd previous occasion				
		HI	Outdoor heat exchanger sensor on 2nd previous occasion				
	AUTO	Discharge pipe sensor on 2nd previous occasion					
27	Cooling	AUTO	Indoor heat exchanger sensor 2 on 2nd previous occasion				
23	Cooling	MED	Error code on 3rd previous occasion	/			
		HI	Room temperature sensor on 3rd previous occasion				
		AUTO	Indoor heat exchanger sensor 1 on 3rd previous occasion				
	Heating	LO	Remote control information on 3rd previous occasion	/			
		MED	Outdoor air temperature sensor on 3rd previous occasion				
		HI	Outdoor heat exchanger sensor on 3rd previous occasion				
	AUTO	Discharge pipe sensor on 3rd previous occasion					
28	Cooling	AUTO	Indoor heat exchanger sensor 2 on 3rd previous occasion				
24	Cooling	MED	Error code on 4th previous occasion	/			
		HI	Room temperature sensor on 4th previous occasion				
		AUTO	Indoor heat exchanger sensor 1 on 4th previous occasion				
	Heating	LO	Remote control information on 4th previous occasion	/			
		MED	Outdoor air temperature sensor on 4th previous occasion				
		HI	Outdoor heat exchanger sensor on 4th previous occasion				
	AUTO	Discharge pipe sensor on 4th previous occasion					
29	Cooling	AUTO	Indoor heat exchanger sensor 2 on 4th previous occasion				
25	Cooling	MED	Error code on 5th previous occasion	/			
		HI	Room temperature sensor on 5th previous occasion				
		AUTO	Indoor heat exchanger sensor 1 on 5th previous occasion				
	Heating	LO	Remote control information on 5th previous occasion	/			
		MED	Outdoor air temperature sensor on 5th previous occasion				
		HI	Outdoor heat exchanger sensor on 5th previous occasion				
	AUTO	Discharge pipe sensor on 5th previous occasion					
30	Cooling	AUTO	Indoor heat exchanger sensor 2 on 5th previous occasion				
21	Cooling	LO	Stop code on previous occasion				
22			Stop code on 2nd previous occasion				
23			Stop code on 3rd previous occasion				
24			Stop code on 4th previous occasion				
25			Stop code on 5th previous occasion				
26			Stop code on 6th previous occasion				
27			Stop code on 7th previous occasion				
28			Stop code on 8th previous occasion				
29			Stop code on 9th previous occasion				
30			Stop code on 10th previous occasion				
Judgement							
Remarks							

Note (1) In the case of indoor heat exchanger sensor 2, match from 26 to 30 the temperature setting of wireless remote control. (Refer to page 26)

ERROR CODE & STOP CODE TABLE – (PREVIOUS)

Models		SRK	ZD, ZF, ZG,	ZDX-S, ZFX-S, ZGX-S	ZEA-S, ZE-S1	YJ-S, YL-S
		DXK	Z3-S			
Flashes in Service Mode		Stop or Error Code	Error Content		Cause	Occurrence Conditions
Run	Timer		Major Category	Minor Category		
1 time	1 time	11	Current Cut	Comp software start	Comp Lock, Wiring short, Comp output is open phase, Outdoor PCB faulty	Compressor start fails 42 times in succession and the final failure is current cut.
	2 time	12		Lower than 20 rps	Service valve closed, Compressor output open phase, EEV faulty	After the compressor starts, it stops due to current cut at less than 20 rps
	3 time	13		20 rps or higher	Service valve closed, Compressor output open phase, EEV faulty	When operation is stopped by current cut at 20 rps or higher.
	4 time	14		Excessive voltage (DC 350V)	Outdoor PCB faulty, Power supply abnormal	When the DC voltage (DC 280V) exceeds 350V
	5 time	15		Short circuit in power transistor (high side)	Outdoor PCB faulty, power transistor damaged	When it is judged that the power transistor was damaged at the time the compressor started
	6 time	16		Current cut circuit breakdown	Outdoor PCB faulty, power transistor damaged	
2 time	1 time	21	Outdoor unit error	PWM calculation results are abnormal	Compressor wires are disconnected, Power transistor is damaged	When PWM calculation results are 0% continued for 3 minutes or longer
	2 time	22		Input is 2A or lower (PWM 90% or higher)	Compressor wires are disconnected, outdoor PCB is faulty	When PWM calculation results of 90% and an input current lower than the set valve continue for 3 minutes or longer
	3 time	23		Abnormal stop 3 times in 20 minutes	Service valve is closed. Compressor output is open phase. Electronic expansion valve is faulty. Low on gas.	When an abnormal stop occurs 3 times with automatic recovery within 20 minutes after the outdoor unit's power supply was turned on.
	9 time	29		Voltage drop	Power supply is faulty. Outdoor PCB is faulty	When the power supply voltage drops during operation.
	7 time	27	Outdoor fan motor error	Outdoor unit's fan motor is abnormal (DC motor only)	Outdoor fan motor faulty. Poor connection. Faulty outdoor PCB	When a fan speed of 75rpm or lower continues for 30 seconds or longer.
3 time	1 time	31	Current Safe	Cooling current safe 1	Overcharge. Compressor lock	When there is a current safe stop in current safe mode 1 mode during cooling operation
	2 time	32		Heating current safe 1		When there is a current safe stop in current safe mode 1 mode during heating operation
	3 time	33		Cooling current safe 2		When there is a current safe stop in current safe mode 2 mode during cooling operation
	4 time	34		Heating current safe 2		When there is a current safe stop in current safe mode 2 mode during heating operation

ERROR CODE & STOP CODE TABLE – (PREVIOUS)

Models		SRK	ZD-S, ZF-S, ZG-S	ZDX-S, ZFX-S, ZGX-S	ZE-S1, ZEA-S	YL-S, YJ-S
		DXK	Z3-S			
Flashes in Service Mode		Stop or Error code	Error Content		Cause	Occurrence Conditions
Run	Timer		Major Category	Minor Category		
3 time	5 time	35	Current Safe	Cooling current safe 3	Overcharge. Compressor lock	When there is a current safe stop in current safe mode 3 mode during cooling operation
	6 time	36		Heating current safe 3		When there is a current safe stop in current safe mode 3 mode during heating operation
	7 time	37		Heating current safe 3 + 3A		When there is a current safe stop in current safe mode 3 + 3A mode during heating operation
4 time	1 time	41	Current Safe	Cooling overload 1 (outdoor temp 36~40°C)	Overcharge. Compressor lock. Overload operation	When there is a current safe stop in overload 1 mode during cooling operation
	2 time	42		Heating overload 1 (outdoor temp 5~12°C)		When there is a current safe stop in overload 1 mode during heating operation
	3 time	43		Cooling overload 2 (outdoor temp 40~45°C)		When there is a current safe stop in overload 2 mode during cooling operation
	4 time	44		Heating overload 2 (outdoor temp 12~17°C)		When there is a current safe stop in overload 2 mode during heating operation
	5 time	45		Cooling overload 3 (outdoor temp 45°C~)		When there is a current safe stop in overload 3 mode during cooling operation
	6 time	46		Heating overload 3 (outdoor temp 17°C~)		When there is a current safe stop in overload 3 mode during heating operation
5 time	OFF	50	Comp overheat	110°C	Service valve closed. Low on gas. Discharge pipe sensor is faulty	When the discharge pipe's sensor exceeds the set value
	1 time	51	Power transistor overheat	110°C	Cooling problem	When power transistor temp exceeds setting value (compressor stops).
6 time	OFF	60	Serial signal error	Signal not received for 1 min & 55 sec	Power supply faulty. Incorrect wiring. Indoor/ outdoor PCB faulty	When 1 min 55sec passes without communication from either the outdoor or indoor being detected correctly
	1 time	61		Faulty interconnect wiring	Connections between indoor and outdoor are faulty. Faulty indoor/ outdoor PCB	When 10 sec passes after the power is on without communication signals from the indoor/ outdoor unit being detected correctly
	2 time	62		Serial transmission error	Indoor/ outdoor PCB faulty. Noise causing faulty operation	When 1 min 50 sec passes without communication signals from either indoor or outdoor unit being detected correctly

ERROR CODE & STOP CODE TABLE – (PREVIOUS)

Models		SRK	ZD-S, ZF-S, ZG-S	ZDX-S, ZFX-S, ZGX-S	YJ-S, YL-S	ZE-S1, ZEA-S
		DXK	Z3-S			
Flashes in Service Mode		Stop or Error Code	Error content		Cause	Occurrence Conditions
Run	Timer		Major Category	Minor Category		
7 time	1 time	71	Rotor lock	Less than 16 rps	Compressor faulty. Compressor output is open phase. EEV is faulty. Overload operation. Outdoor unit PCB is faulty.	After the compressor starts, when it stops at less than 16 rps due to rotor lock
	2 time	72		16 rps or higher		When the comp stops at 16rps or higher due to rotor lock
	3 time	73		Phase switching defects (U phase)	Compressor is faulty. Compressor wiring is faulty. Outdoor unit PCB is faulty	When compressor start fails 42 times in succession and the reason for the final failure is rotor lock.
	4 time	74		Phase switching defects (V phase)		
	5 time	75		Phase switching defects (W phase or can't distinguish)		
	6 time	76		Comp software start (within 4 sec after phase switching)		
8 time	OFF	80	Protective control operation	Indoor unit fan motor is abnormal	Faulty connection. Faulty fan motor. Indoor PCB faulty	When indoor fan motor is detected to be running at 300rpm or lower.
	1 time	81		Discharge pipe sensor is abnormal (anomalous stop)	Sensor wire disconnected faulty connection	When a disconnected signal (temp below 7°C) is sent for 15 sec or longer as the sensor data after the comp speed is 0rps or higher cont. for 9 min.
	2 time	82		Indoor heat exchanger sensor is abnormal (anomalous stop)	Sensor wire disconnected faulty connection	When a temperature of -20°C or lower is sensed cont. for 40 min during heating operation. (Compressor stops)
	3 time	83		Outdoor heat exchanger sensor is abnormal (anomalous stop)	Sensor wire disconnected faulty connection	When a temperature or - 50°C or lower is sensed cont. for 40 min during heating operation. Compressor stops
	4 time	84		Anti -condensation control	High humidity. Faulty humidity sensor	Anti-condensation prevention control is operating
	5 time	85		Anti-frost control	Indoor fan speed drops. Indoor heat exchanger sensor short circuit	When the anti-frost control operates and the compressor stops during cooling operation.
	6 time	86		High pressure control	Heating overload. Indoor fan speed drops. Indoor heat exchanger sensor short circuit	When high pressure control operates during heating operation and the comp stops.
	7 time	87		Comp overheating protection control	Short of gas. Discharge pipe sensor is faulty. Closed service valve.	When compressor overheating protective control operates and the compressor stops.
	8 time	88		Refrigeration cycle system protective control	Service valve closed. Short of gas.	When refrigerant cycle system protective control operates.

ERROR CODE & STOP CODE TABLE – (CURRENT)

Models		SRK	ZJ-S, ZJ-S1, ZMA-S, ZRA-W, ZSA-W	ZHX-S, ZIX-S, ZJX-S, ZMXA-S, ZSXA-W	ZK-S, ZL-S	YRA-W, YSA-W
		SRR	ZM-S			
		DXK	ZJ-S, Z4-S, ZL-S, ZMA-S, ZRA-W, ZSA-W			
Flashes in Service Mode		Stop or Error Code	Error Content	Cause	Occurrence Conditions	
Run	Timer					
OFF	OFF	0	Normal	-	-	
	1 time	01	Error of wired remote control wiring	Broken wired remote control wire, defective indoor PCB	The wired remote control wire Y is open. The wired remote control wires X and Y are reversely connected. Noise is penetrating the wired remote control lines. The wired remote control or indoor PCB is faulty.	
	5 time	05	Cannot receive signals for 35 sec (if communications have recovered)	Power supply is faulty. Power supply cables and signal lines are improperly wired. Indoor/ outdoor PCBs are faulty.	When 35 sec passes without communications signals from either the outdoor or indoor unit being detected correctly	
3 time	5 time	35	Cooling high pressure control	Cooling overload operation. Outdoor fan speed drops. Outdoor heat exchanger sensor is short circuit.	When the outdoor heat exchanger sensor's value exceeds the set value.	
	6 time	36	Compressor over heat (115°C)	Low on gas. Discharge pipe sensor is faulty. Service valve is closed	When the discharge pipes sensor value exceeds the set value.	
	7 time	37	Outdoor heat exchanger sensor is abnormal.	Outdoor heat exchanger faulty. Poor connections	When a temp of -55°C or lower is sensed cont. for 20 sec while the power is on or after the outdoor units speed has continued at Orps or higher for 2 min. (The comp stops)	
	8 time	38	Outdoor air temp sensor is abnormal	Outdoor air temp sensor wire is faulty. Poor connection	When a temp of -55°C or lower is sensed cont. for 20 sec while the power is on or after the outdoor units speed has continued at Orps or higher for 2 min. (The comp stops)	
	9 time	39	Discharge pipe sensor is abnormal (anomalous stop)	Discharge pipe sensor wire is faulty. Poor connection	When a temp of -25°C or lower is sensed cont. for 20 sec after the outdoor units speed has continued at Orps or higher for 10 min. (the comp stops)	
4 time	OFF	40	Service valve (gas side) closed	Service valve closed, or faulty outdoor PCB	If the inverter output current exceeds set value within 80 seconds, after compressor ON in heating	
	2 time	42	Current cut	Service valve closed. Compressor locked/faulty. Outdoor PCB faulty. EEV faulty.	Compressor start fails 42 times in succession and final reason for failure is current cut.	
	7 time	47	Active filter voltage error	Defective active filter.	When the wrong voltage connected for the power supply. When the outdoor control PCB is faulty.	
	8 time	48	Outdoor fan motor abnormal	Poor connection. Faulty fan motor. Faulty PCB.	When a fan speed of 75rpm or lower continues for 30 sec or longer.	

ERROR CODE & STOP CODE TABLE – (CURRENT) – continued

Models		SRK	ZJ-S, ZJ-S1, ZMA-S, ZRA-W, ZSA-W	ZHX-S, ZIX-S, ZJX-S, ZMXA-S, ZSXA-W	ZK-S, ZL-S	YRA-W, YSA-W
		SRR	ZM-S			
		DXK	ZJ-S, Z4-S, ZL-S, ZMA-S, ZRA-W, ZSA-W			
Flashes in Service Mode		Stop or Error Code	Error Content	Cause	Occurrence Conditions	
Run	Timer					
5 time	1 time	51	Short circuit in the power transistor (high side) Current cut circuit breakdown	Outdoor PCB is faulty, power transistor damaged	When it is judged that the power transistor was damaged at the time the compressor started.	
	7 time	57	Refrigeration cycle system protective control	Service valve closed. Short of gas.	When the refrigeration cycle protective control operates	
	8 time	58	Current safe	Refrigerant is overcharged. Compressor locked. Overload operation.	When there is a current safe during operation.	
	9 time	59	Compressor wiring is disconnected. Voltage drop. Low speed protective control	Compressor wiring is disconnected. Power transistor is damaged. Power supply construction is defective. Outdoor PCB is faulty.	When the current is 1A or less at the time the compressor started. When the power supply voltage drops during operation. When the outdoor unit's speed is lower than 26rps for 60 min.	
6 time	OFF	60	Rotor lock	Overload operation. Faulty compressor. Faulty EEV. Faulty outdoor PCB.	After the compressor starts, when the compressor stops due to rotor lock.	
	1 time	61	Connection lines between the indoor & outdoor are faulty.	Connection line is faulty. Indoor or outdoor PCBs are faulty.	When 10 sec passes after the power on without communications signals from the indoor or outdoor being detected correctly	
	2 time	62	Serial signal error	Indoor or outdoor unit PCBs are faulty. Noise causing faulty operation.	When 7 min 35 sec passes without communication signals from indoor or outdoor unit being detected correctly.	
8 time	OFF	80	Indoor fan motor is faulty	Indoor fan motor is faulty. Poor connection. Faulty indoor PCB.	When the indoor fan motor is detected to be running at 300 rpm or lower	
	2 time	82	Indoor heat exchanger sensor abnormal	Indoor heat exchanger sensor wire faulty. Poor connection.	When a temp of -28°C or lower is sensed cont. for 40 min during heating.	
	4 time	84	Anti-condensation control	High humidity condition. Faulty humidity sensor.	Anti-condensation prevention control is operating.	
	5 time	85	Anti-frost control	Indoor fan speed drops. Indoor heat exchanger sensor is faulty	When the anti-frost control operates and the compressor stops during cooling operation.	
	6 time	86	Heating high pressure control	Heating overload operation. Indoor unit fan speed drops. Indoor heat exchanger sensor is short circuit.	When high pressure control operates during heating operation and the compressor stops.	
	7 time	87	Drain trouble	Defective drain pump (DM), broken drain pump wire, anomalous float switch operation, defective indoor PCB	If the float switch OPEN is detected for 3 seconds continuously or if the float switch connector or wire is disconnected	

RC-E5 OPERATION DATA

Operation data can be checked with remote control unit operation.

- ① Press the **CHECK** button.
The display change “**OPER DATA** ▼”
- ② Press the **(SET)** button while “**OPER DATA** ▼” is displayed.
- ③ When only one indoor unit is connected to remote controller, “**DATA LOADING**” is displayed (blinking indication during data loading).
Next, operation data of the indoor unit will be displayed. Skip to step ⑦.
- ④ When plural indoor units is connected, the smallest address number of indoor unit among all connected indoor unit is displayed.

[Example]:

“**SELECT I/U**” (blinking 1 seconds) → “**I/U000** ▲” blinking.

- ⑤ Select the indoor unit number you would like to have data displayed with the **▲** **▼** button.
- ⑥ Determine the indoor unit number with the **(SET)** button.
(The indoor unit number changes from blinking indication to continuous indication)
“**I/U000**” (The address of selected indoor unit is blinking for 2 seconds.)

↓

“**DATA LOADING**” (A blinking indication appears while data loaded.)

Next, the operation data of the indoor unit is indicated.

- ⑦ Upon operation of the **▲** **▼** button, the current operation data is displayed in order from data number 01.

The items displayed are in the above table.

*Depending on models, the items that do not have corresponding data are not displayed.

- ⑧ To display the data of a different indoor unit, press the **AIR CON NO.** button, which allows you to go back to the indoor unit selection screen.

- ⑨ Pressing the **ON/OFF** button will stop displaying data.

Pressing the **(RESET)** button during remote control unit operation will undo your last operation and allow you to go back to the previous screen.

⊙If two (2) remote controllers are connected to one (1) inside unit, only the master controller is available for trial operation and confirmation of operation data. (The slave remote controller is not available.)

●Details of Compressor protection status No. 33

No.	Contents of display	In case of FDC100-140 refer to
"0"	Normal	
"1"	Discharge pipe temperature protection control	P.25, (6).(a).1
"2"	Discharge pipe temperature anomaly	P.25, (6).(a).2
"3"	Current safe control of inverter primary current	P.27, (6).(g)
"4"	High pressure protection control	P.25, (6).(b).1), P.26, (6).(c).1)
"5"	High pressure anomaly	P.25, (6).(b).2)
"6"	Low pressure protection control	P.26, (6).(e).1)
"7"	Low pressure anomaly	P.26, (6).(e).2)
"8"	Anti-frost prevention control	P.27, (6).(k)
"9"	Current cut	P.27, (6).(g)
"10"	Power transistor protection control	P.27, (6).(h)
"11"	Power transistor anomaly (Overheat)	P.27, (6).(i)
"12"	Compression ratio control	P.26, (6).(f)
"13"	Spare	
"14"	Dewing prevention control	P.28, (6).(l)
"15"	Current safe control of inverter secondary current	P.27, (6).(g)
"16"	Stop by compressor rotor lock	
"17"	Stop by compressor startup failure	P.28, (6).(q)

Number	Data Item
01	OPER MODE (Operation Mode)
02	SET TEMP (Set Temperature)
03	RETURN AIR (Return Air Temperature)
04	SENSOR (Remote Controller Thermistor Temperature)
05	THI-R1 (Indoor Heat Exchanger Thermistor / U Bend)
06	THI-R2 (Indoor Heat Exchanger Thermistor / Capillary)
07	THI-R3 (Indoor Heat Exchanger Thermistor / Gas Header)
08	I/U FANSPEED (Indoor Unit Fan Speed)
09	DEMAND (Frequency Requirements)
10	ANSWER (Response Frequency)
11	I/U EEV (Pulse of Indoor Unit Expansion Value)
12	TOTAL I/U RUN (Total Running Hours of The Indoor Unit)
21	OUTDOOR (Outdoor Air Temperature)
22	THO-R1 (Outdoor Heat Exchanger Thermistor)
23	THO-R2 (Outdoor Heat Exchanger Thermistor)
24	COMP (Compressor Frequency)
25	HP (High Pressure)
26	LP (Low Pressure)
27	Td (Discharge Pipe Temperature)
28	COMP BOTTOM (Comp Bottom Temperature)
29	CT (Current)
30	TARGET SH (Target Super Heat)
31	SH (Super Heat)
32	TDSH (Discharge Pipe Super Heat)
33	PROTECTION No. (Protection State No. of The Compressor)
34	O/U FANSPEED (Outdoor Unit Fan Speed)
35	63H1 (63H1 On/Off)
36	DEFROST (Defrost Control On/Off)
37	TOTAL COMP RUN (Total Running Hours of The Compressor)
38	O/U EEV1 (Pulse of The Outdoor Unit Expansion Valve EEVC)
39	O/U EEV2 (Pulse of The Outdoor Unit Expansion Valve EEVH)

Note(1) Operation data display on the remote controller.

•Data is displayed until canceling the protection control.

•In case of multiple protections controlled, only the younger No. is displayed.

Note(2) Common item.

① In heating mode.

During protection control by the command signal for reducing compressor frequency from indoor unit, No. "4" is displayed.

② In cooling and dehumidifying mode.

During protection control by the command signal for reducing compressor frequency from indoor unit, No. "8" is displayed.

MHIAA Pty. Ltd. - Offices Contact Detail			
Web		www.mhial.com.au	
NSW & ACT		Ph. + 61 2 8571 7977	Fax. + 61 2 8571 7992
QLD & NT	Brisbane	Ph. + 61 7 3885 0334	Fax. + 61 7 3385 0489
	Townsville	Ph. + 61 7 4775 1169	Fax. + 61 7 4475 6690
VIC TAS SA		Ph. + 61 3 9544 3400	Fax. + 61 3 9544 3911
WA		Ph. + 61 8 9248 5040	Fax. + 61 8 9248 8562
New Zealand		Ph. (0011 64) 952 53 019	Fax. (0011 64) 957 99 665

MRE Spare Parts PTY. LTD.	Ph. + 61 2 9600 7444	info@mrespareparts.com.au
	Fax. + 61 2 9600 8044	www.mrespareparts.com.au
Address	U5/376 Newbridge Road, Moorebank, NSW Australia 2170	

